



Scoreboard Operator's Instructions

MPC Control / Model Code 134 Basketball

<https://bit.ly/scoreboard-control-134-basketball>



- Set** Press before function key for direct entry mode
- Next Poss.** Toggle Next Possession
- Bonus** Toggle Bonus
- Horn** Start | stop horn*
- Time On** Start | stop clock*




- Yes** Confirm input
- No** Cancel an operation
- Home Score** Enter, add, or change score
- Guest Score** Enter, add, or change score


*Same as control on hand held switch

How To


Set the time (8:00) and period for the first period of play.



Add (2 points) to the HOME or GUEST score




Set the HOME or GUEST score directly (to 31)




Toggle the next possession



Clear (both) next possession



Set the bonus (>=5 fouls per team per period)



The first time you press Next Poss. or Bonus always displays the current status. Press any key to exit.